
Re-position kit for main PCBVertical home ventilation units

Rev. 1.1


Required tools




Important!

- •Only trained and certified personnel is allowed to replace parts
- •Turn off all power to the unit before starting the work
- •Make sure that all work has been carried out before the power is switched back on
- •Be sure to observe ESD measures to avoid damaging the PCB due to static electricity


Remove front




Remove existing PCB




Remove sensor wire harness assembly




Overview, new PCB position




Pre-drill holes



Mount and secure PCB box




Mount PCB holders




Mount the five PCB holders inside the new metal housing. Openings facing in the directions shown

Mount PCB




Mount earth wires




- Mount the existing earth wire to the PCB box metal
- Mount the new supplied earth cable from PCB box left side to filter reset switch bracket

Locate components




Connect existing cables to PCB


Route all cables into the new PCB covers lower sides, right or left, and connect



New sensor wire harness assembly



Place sensor cables




- 1. Connect new sensor plug to PCB (J7)
- 2. Route and fasten each sensor cable, one by one, according the previous illustration


Secure T1 sensor




Secure T2 sensor



Secure T3 and Humidity sensor



Secure T4 sensor



Larger size units, surplus


cable hidden behind box


Finalizing

1: arrange and secure cables

2: re-mount front cover

Smaller size units, surplus cable in front of PCB





The supplier can accept no responsibility for possible errors and changes

