




INSTRUCTION

Wall duct for CDP 40T-50T-70T













x





Dantherm® CONTROL YOUR CLIMATE















	CDP 40T	CDP 50T	CDP 70T
V	998	1147	1483
W	466	616	951
X	603	753	1088




Dantherm® CONTROL YOUR CLIMATE
































Dantherm A/SMarienlystvej 65
7800 Skive
Denmark

support.dantherm.com

